

Product **Information**



SO1800 Metal Magazine Handler

May 2009

METAL MAGAZINE VS TUBE-TO-TUBE



SO1800 Metal Magazine

Metal Magazine Handler

- 1 Loader / 1 Unloader
- 1 Auto Loader/Unloader for all 4 tracks
- 1 Manual bin, optional 1 additional manual bin


Tube-to-Tube Handler

- 2 Loaders / 2 Unloaders
- 1 Auto Loader/Unloader per track set
- 4 Manual bins, optional 4 additional manual bins



SO1800 Tube-to-Tube

METAL MAGAZINE LOADER AND GRIPPER (SIDE/FRONT VIEW)



SO1800 metal magazine loader



SO1800 metal magazine gripper at loader


Product Information

SO1800 Metal Magazine Handler


Rasco
A Cohu Company

May 2009

METAL MAGAZINE UNLOADER



SO1800 metal magazine sort shuttle



SO1800 metal magazine unloader

TRAY SPECIFICATION AND EXCHANGE

- Tray length: min. 520 mm, max. 540 mm, variable by 4 screws
- Tray width: min. 43.6 mm, max. 66 mm
 - Gripper: Exchange centering plate (partly) and device mark
 - Stack loader/unloader: adjustment
 - Unloader: Exchange centering (partly)
 - Manual unloader: Exchange cover, centering (partly) and air acceleration block
- Tray height: min. 5 mm, max. 7 mm
- Rails: Up to 6
- Input/output capacity: 25 trays

S E R V I C E

For more information please ask your local Rasco service team or contact service@rasco.de

Contact: Germany: Rasco GmbH, Geigelsteinstraße 6, 83059 Kolbermoor/Germany, Phone: +49-8031-2337-0, Fax: +49-8031-2337-10
 Asia: Delta Design, Inc./Rasco Asia, 3 Kallang Sector #01-06, Singapore 349278, Phone: +65-6288-6949, Fax: +65-6289-6949
 USA: Delta Design, Inc./Rasco US, 12367 Crosthwaite Circle, Poway, CA 92064-6817, Phone: +1-858-848-8000, Fax: +1-858-848-8180
 email: info@deltad.com, info@rasco.de; web: www.deltad.com, www.rasco.de